

DMX PROTOCOL

CHANNEL	FUNCTION	DMX	DESCRIPTION
1	Dimmer	000-255	From dark to bright
2	Strobe	000 - 007	NO strobe
		008 - 255	Strobe speed from slow to fast
3	CT	000-255	CT Adjustment
4	Macros	000-016	Nil
		017-024	White(CT 10000K)
		025-032	White(CT 7200K)
		033-040	White(CT 5600K)
		041-048	White(CT 3200K)
		049-056	Cyan
		057-064	Yellow
		065-072	Magenta
		073-080	Red
		081-088	Green
		089-096	Blue
		097-104	Light Blue
		105-112	Amber
		113-120	Orange
		121-128	Pink
129-255	Shift between colors of Red, Green and Blue		
5	R	000-255	
6	G	000-255	
7	B	000-255	
8	W	000-255	

INDICATION OF LED DIGITAL TUBE

DMX Indication	Signal	LED	ON	DMX signal
			OFF	NO DMX signal