


| CHANNEL | EFFECT |
|---------|---------------|
| 1 | STOP / STROBE |

• **STOP / STROBE - channel 1**



| BIT | % | EFFECT |
|-----------|------------|---|
| 244 - 255 | 95.5 - 100 | OPEN |
| 243 | 95.0 | FAST STROBE (2 flash/sec) |
| 140 | 54.7 | SLOW STROBE (1 flash/4 sec) |
| 139 | 54.2 | THE BANDS ARE PROGRESSIVELY OBSCURED FROM RIGHT TO LEFT |
| 65 | 25.5 | THE BANDS ARE PROGRESSIVELY OPENED FROM RIGHT TO LEFT |
| 64 | 25 | |
| 7 | 3.0 | |
| 0 - 6 | 0.0 - 2.5 | CLOSED |