

DMX functions

The JEM K1 Hazer™ address setting must match the DMX address allocated to it on the controller. To set the address, see “Setting the DMX base address” on page 13. The JEM K1 Hazer™ requires two DMX channels.

DMX channel 1	Function: Haze Density
0-19	Standby
20-219	Proportional output level control
220-255	Prime

DMX channel 2	Function: Fan Speed
0-219	0-100%, heaters on
220-244	Auto fan mode
245-255	Machine shutdown, heaters off