

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

Spare Parts List of ADB Europe DS 205 ©

30004	Fixed male connector
30014	Grab handle
30036	2m cable w/ CEE22 socket & no plug C.EUROPE
30560	door latch
32050	safetly screw
32233	lamphouse door
32260	1/2 counter mirror
32415	aluminium reflector
32426	backplate subassembly
32438	lampholder/fan assembly
32440	fan
32449	GY 16 lampholder kit
32481	yoke and clamping handle subassembly
33410	lens fastener
33865	fixing screw for door latch
34754	clutch release handle
36300	condenser lens Ø 68
36309	Intermediate PC lens Ø 114,3
36352	intermediate lens kit
36354	optical subassembly
1001.31.356	CEE 22 socket kit
1000.36.930	set of 4 beam shaping shutters
1000.40.085	retention ring for gobo size A
30079	TCC M4x10 black screw
30092	2 kW cassette
30412	Focus knob
30485	Lens tube door
30560	Door latch
32269	New cassette
32312	Rotation control knob
33410	Lens fastener
33865	Fixing screw for door latch
34606	Lens joint
36302	Zoom 2 PC lens Ø114.3 / RC150 PC114/RC150
36303	Zoom 1 PC lens Ø114.3 / RC163 PC114/RC163
36307	Zoom 3 PC lens Ø203 / RC216 PC203/RC216
1001.31.910	Old cassette replacement kit K/CAS/DS/2
30241	
31771	
30001	
31470	
30318	
30493	



Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

31719
30492
30359
30907
31464
30906
40606
30578
30035
32531
40641
30403
32200
32201
40688
32475
41316
32311
30537
40687
30101
30417
30416
32908
30020
32071
33965
34412
31469
32059
30359
32950
30482
30001
32448
32433
40623
32619
34606
32446
32447
32042
32041
40619
32437



Your online store for all stage lighting spare parts <https://lightspares.com>
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

32435
30620
30371
32009
32007
32011
30137
33865
30560
34413
32220
32811
33965
33966
30023
30046
30907
30345
32432
32904
32403
32444
32417
32472
32016
40630
32017
31452
30337
30343
30250
30018
30001
30207
30016
31784
30210



Your online store for all stage lighting spare parts <https://lightspares.com>
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria