

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

**Complete Spare Parts List of
ROBE DMX Control 24 CT**

13050062 Connector fem. JACK 63 angular f. PCB
13050600 Connector PAW -254-04 PSH02-04P Gold
13050015 Fuse socket PCB
13040515 IC EEPROM 24C64 DMX Control 24/E V 1.0/IC2
13040516 IC EEPROM 24C64 DMX Control 24/E V 1.0/IC3
13040517 IC EEPROM 24C64 DMX Control 24/E V 1.0/IC4
13040518 IC PIC 16C57 DMX Control 24 V1.0/IC1
11010794 Panel - main
13030086 PCB Main EZX1F
13030044 PCB2 Source EZX11
12050077 Plexiglass f. display 19x13
13050064 Plug f. line cord - male GSD781
13050044 Plug male PCB PAW-254-04
17030018 Spacer CS10 plastic
12010001 Spacer D6xL11 M3
13050048 Switch - Key 501
13010018 Transformer BWEI 3052051 230V/9V,3VA
13170299 Wires set f. DMX Control 24 230V Power
13170298 Wires set f. DMX Control 24 without Power-wires
13050053 XLR female 3-pin, PCB, angle, FDPH

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**