

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

Complete Spare Parts List of NIETHAMMER

Enispot HPS 117

N30-651	Filterhalter	lens holder
N30-388	Frontlinse	front lens
H624-60	Frontlinse	front lens
N11-271	Tubus 17 grd	tube 17°
N30-263	Zwischenlinse 100mm	intermediate lens 100mm
H624-55	Zwischenlinse 100mm	intermediate lens 100mm
N27-525	Blendenschieber	shutter
N27-509	Irisblende	iris
N25-701	Gobohalter	gobo holder
N13-631	Asph. Kondensorlinse	aspherical condensor lens
H626-06	Asph. Kondensorlinse	aspherical condensor lens
	Linsenhalter ohne	
N28-094	Linse	lensholder without lens
N16-164	Fassung G9,5	lampholder G9,5
H642-37	Fassung G9,5	lampholder G9,5
N28-135	Fassungshalter	terminal block
N27-260	Hohlspiegel	concave mirror
H616-30	Hohlspiegel	concave mirror
N19-423	HPS Grundgerät	HPS basic device
N30-510	Gehäuse	housing

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**