

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

**Complete Spare Parts List of
ROBE FAZE 800 FT Pro**

13051672	Air pump Faze 800 FT Pro
13051474	Breaker ZE-805 5A
13050686	Connector NEUTRIK NAC3MPA-1
16030061	Fan - turbine
13030811	Filter F-3E-EMI
13050719	Heater group Fog 800 FT/Fog 850 FT/Faze 800 FT Pro
13031145	Infrared Ray Liquid Sensor PCB
13031323	Infrared Ray Liquid Sensor PCB - Faze 800 FT Pro
13031152	PCB Control Faze 800 FT Pro
13051769	PCB DMX 3 pin
13051770	PCB DMX 5 pin
13030898	PCB Main Faze 800 FT Pro
99013601	Piping assembly (Faze 800 FT Pro)
13051607	Pump (240V 50Hz) Faze 800 FT Pro
17030715	Tank Faze 800FT

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**