

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of COEMAR Infinity ACL S

272.334	lens locking ring
LE94	fresnel lens
A-2138	cover assembly
A-2136	base cover assembly
A-2137	yoke cover
IN115	rotation gear
8697.72	spacer 0,2mm
MMD384.258	spacer 3mm
MMD383.258	spacer 2mm
A-G002	gobos holder
A-272.152	rot. Gobos wheel
A-G003	gobos supp. w/reset
272.151	iris holder
FO5044	iris assembly
MMD431	spacer 17mm
IN82	gear
EL0107441	sensor
272.157	sensor holder
272.150	gobos plate
MMD284	spacer 8mm
CN23	24 poles connector
MT36	motor 39x39 shaft 28
CD16/1	MXL belt
IN128	MXL pulley
272.156	motor holder
MT33	motor 39x39 shaft 9
MT09	motor 39x39 shaft 30
272.068	motor holder
272.239	antireflex plate
MO27	gobos locking spring
VT285/B	blue filter d=40
VT285/UV	UV filter d=40
FC47	CTO filter d=40
VT285/AR	orange filter d=40
VT285/R	red filter d=40
A-272.070	colour wheel asm.
MMD331	flared spacer 1mm
MMP401	pole 6,5mm
MMD284	spacer 8mm
CN23	24 poles connector
275.135	main plate
272.069	motor spacer

MT33	motor 39x39 shaft 9
MT51	motor 39x39 shaft 12
272.075	upper adj.cursor
272.140	motor cover
272.160	cover plate
IN127	movement gear
MMP405	pole mm 28,5
RL645	washer d=6
272.064	lower adj. Cursor
272.039	spacer 0,2mm
MMP400	pole 14,5 mm
MMP399	gear pole
MM6362	spacer
MT26	motor 39x39 shaft14
EL050288	sensor
MT36	motor 39x39 shaft 28
A-VT304/SX	yellow filter left
272.123	gear
CU31	flared bearing
A-VT304/DX	yellow filter right
IN95/1	gear
CU32	flared bearing
A-VT302/SX	magenta filter left
A-VT302/DX	magenta filter right
A-VT300/SX	cyan filter left
A-VT300/DX	cyan filter right
A-VT287/L	right dimmer
A-VT286/L	left dimmer
272.133	gear
272.128	right blackout
272.129	left blackout
272.085	group holder support
A-272.087	front heat shield
272.089	right rear shield
272.093	left side panel
272.234	connector holder
MR316	connector
MET04	thermal switch
272.090	rear heat shield
272.065ASM	light shield
GA15/9	plastic washer
GA15/5	locking pin
GA15/3	spring
PA485	lamp hatch
L105820	300/2 fastfit lamp
GA15/4	holding washer
VI548	4x40 screw

PA478	lamp hatch panel
GA15/1	locking receptacle
272.081	lamp group chassis
A-272.251	air channel
VE49	fan
272.088	left heat shield
MM5259/1	spacer
MO1093	spring
272.080	lampholder support
PR19	lampholder
MOT1899	molla
272.112	reflector holder
PAS16/1	reflector
FUS015	strut
272.238	bulkhead
272.211	left group holder
GA15/1	receptacle
272.096ASM	rear header
272.107	rear housing holder
MMA94	pivot pole
272.210	right group holder
272.029	counterweight
272.117	cover holder
PLA171	lens holder
272.335	lens locking ring
MT22	motor 55x55
MV23	shock absorber
EL1005408	sensor
8697.86	sensor holder
260.084	motor holder
MMD253	spacer 29mm
MMD11	spacer 6mm
MMD381	teflon spacer
MM51/1L	encoder spacer
IN93	pulley w/encoder
CD24	MXL belt
CU24	bearing
MMP321	tightening pin
IN36/4L	MXL pulley
8661.273	tightening holder
MMF196	pulley flange
272.062	yoke flange
260.160	bearing locking
272.053ASM	front cover
CU02/2L	bearing 6006
259.011	locking sector
MMD387	reset holder

260.162	pole guide
MMD403	spacer 1mm
272.260	hook holder
GA15/1	receptacle
MMP353	tilt hook pole
260.145	butterfly plate
GR5452	friction grain
EL1007455	4 motors PCB
EL1007456	5 motors PCB
MM5259/1	spacer 10mm
272.058	PCB holder
8661.69	friction grain holder
272.055	yoke holder
MMP352	hook
MMA79	sector holder
287.023	lower sector
272.056	cables cover
MMD378	teflon washer
272.054ASM	rear cover
AC17	ignitor
272.050ASM	assembled yoke
EL0906433B	main PCB
VE47	60x60 fan
272.008	fan holder
AL48	electronic ballast
MM6362	spacer mm5
MEI04	main switch
272.014	PCB holder
PO1339	fuse holder
PRS04	cable holder
272.013	ballast holder
PA472	warning panel
PA473	fuses panel
GA15/1	receptacle
272.002	handle holder
MMG149	handle
EL1204380	XLR5 DMX connector
EL0605398	XLR3 DMX connector
EL1108477	PCB holder
272.263	ethernet connector
PA481	dmx panel
MMD320	spacer
VO04	foot d=25
PA474	lower cover plate
272.009	reinforcement plate
272.016	safety hook
8681.79	receptacle spacer

GA11/2	receptacle
EL1006436B	display
MV88	insulator
272.012ASM	lower base plate
MR07	terminal block
MM2395	nut PG 13,5
272.015	power supply holder
AL51	switching PWR supply
VE51	60x60 fan
RL11	seger
8717.51	spacer
MMD412ASM	bearing holder
CD09	MXL 170 belt
IN36/3L	MXL 130 pulley
8697.100	reset ring
8697.101	upper reset ring
8697.102	reset plate
RL10	seger
8720.32	reset ring
MMD187	spacer mm5
	ballast ring
8720.64	reinforcement
272.006	rotating shaft supply
MMA93	shaft
MT22	motor 55x55
8681.75	motor holder
MM6362	spacer 5mm
EL1005408	sensor
MM51/1L	encoder spacer
IN93	pulley w/encoder
8681.76	tightening holder
MMP258	tightening pole
CU23	spacer bearing
MMD196	teflon spacer
8697.85	tightening locking
MV76	neoprene washer

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**