

Order your Spare Parts online here -> [lightspares.com](https://lightspares.com) Worldwide Express Delivery  
Part or number not found? Send us a request! -> [Contact us!](#)

### Spare Parts List of Pani BP 1-2 ©

56-01	Housing Main Assy
5302	Cooling Fins
68-36-	Holding Plate for Ventilator
	Rear Section Housing Main Assy.
56-02-	No.:
56-01-13	Reflector Adjustment Screws
56-01-31	Ball Nuts
56-01-19	Lamp Adjustment Springs
61-11-05	Floating Lamp Support
61-11-06	Fixed Lamp Support
61-11-08	Terminal Block for Lamp
61-11-09	Lamp Support Case (Right)
61-11-11	Case Clamp
PN10108	Wood Grip
SpKu.83	Reflector Ø 112
12232vern.	Overlay
QLZ06/0018-A17-2513-15dg	Ventilator
56-01-30	Reflector Retainer Springs
56-03-	Igniter Housing Main Assy. No:
31.11.000	Connector
42.50.06.00	Annex Housing HB 6. AG- LB
42.10.06.00	Pin Insert HB 6. Sti. S
56-04-	Yoke (Stirrup) Main Assy. No.:
56-01-23/a	Yoke
56-01-28	Base
	Telescoping Adjustment Clamping
5351	Piece
5352	Telescoping Adjustment Guides
5306	Telescoping Adjustment Spacers
	Telescoping Adjustment Cross
GN6335.4-SK-32-M6-10	Grip Bolt
	Telescoping Adjustment Three
GN5340-100-M8-E	Star Grip
	Ventilator Housing Main Assy.
56-05-	No.:
56-05-14	Housing: Ventilator
56-05-15	Cover
	Glide Piece for Telescoping
56-01-27	Adjustment
QLZ06/1800-A18-2513-16dg	Ventilator
M8DIN415	Wing Nuts
56-06-	Optical Materials Main Assy. No.:
	Electro-Mech. Parts Main Assy.
56-07-	No.:



Order your Spare Parts online here -> [lightspares.com](https://lightspares.com) Worldwide Express Delivery  
 Part or number not found? Send us a request! -> [Contact us!](#)

42.32.06.03	Connector Housing HB. 6. StS. 1. 13	
42.20.06.00	Case Insert HB. 6. Bu. S	
52.00.08.60	Bushing SH. 13,5	
52.00.20.30	Rubber Sleeve SNR 13/13	
1401.0396674	Connector with Strain Relief M 16 S	
1401.0432714	Pin Support E 2- 6 St+PE	
1440.0319.804	Contact Pins 1, 58 C 1,5	
1440.0319.564	Contact Case CB1,58C1,5	
1441.0388491	Spout (Tülle) T 1- 12/13	
71111506	Housing	For Ballast BC 1200/E
71104762	Capacitor box	For Ballast BC 1200/E
71115310	Bottom	For Ballast BC 1200/E
71011955	Front Panel	For Ballast BC 1200/E
81014176	Connector Plate	For Ballast BC 1200/E
87534075	Cable Clamp	For Ballast BC 1200/E
93643016	Input Cable	For Ballast BC 1200/E
84620063	Terminal board	For Ballast BC 1200/E
88445000	Power relay	For Ballast BC 1200/E
88502120	Magnetothermal Protection	For Ballast BC 1200/E
84610156	Earth terminal	For Ballast BC 1200/E
88205275	Resistor	For Ballast BC 1200/E
88320030	Capacitors	For Ballast BC 1200/E
63090151	Reactor	For Ballast BC 1200/E
78800550	Controls Pb Ass'y	For Ballast BC 1200/E
88901500	Slide Switch	For Ballast BC 1200/E
79000172	Female Output connector Ass'y Magnetothermal Protection	For Ballast BC 1200/E
87435204	Frame	For Ballast BC 1200/E
74140003	Frame for Pushbuttons	For Ballast BC 1200/E
88430120	Voltage selector switch	For Ballast BC 1200/E
87444277	Voltage Selector Knob	For Ballast BC 1200/E
88941400	Shock absorber H 25	For Ballast BC 1200/E
88941401	Shock absorber H 15	For Ballast BC 1200/E
87330020	Feet	For Ballast BC 1200/E