

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

Spare Parts List Coemar LedKo Softprofile Fresnel©

PLA186/1	SAFETY HOOD
V1539	4X10 SCREW
GA-OTTICALEDKO	OPTIC GROUP
298.041	OPTICS HOLDER
DA220	CAP NUT Ø03
DA231	SELF LOKCK NUT
VI1293	4X14 SCREW
298.004	YOKE PLATE
RVSP3X12	3X12 SCREW
VI530	3X14 SCREW
DA215	NUT Ø06
MA15	KNOB 6X40
PLA177	BODY CASING
298.059	RIGHT SHIELD
VI6644	SCREW 2.9X13
GA-298.012	REAR PANEL HOLER
VI554	SCREW 6X30
MMD446	SPACER H=38
MMD445	SPACER H=30
VI534	LED GROUP
VE56	3X30SCREW
VI579	FAN
RL838	SCREW 8X20 WASHER ØE24 ØI8
MA05	HANDLE
RL412	WASHER
298.003	YOKE
VI591	LOCK BOLT
RL734	CUP WASHER
DA235	SELF LOCK NUT Ø8
DA241	SELF LOCK NUT Ø3
298.060	LEFT SHIELD
298.024ASM	FAN HOLDER
AL42	POWER SUPPLY UNIT
MMD451	PCB FASTENER
MV108	MYLAR INS. SHEET
298.062	PCB HOLDER
MV22	PCB FASTENER
EL0108461L	CONTROL PCB
EL0909462	DISPLAY PCB
MM5259	SPACER H=10
MV6371	DISPLAY SCREEN
RL1297	WASHER Ø03



Your online store for all stage lighting spare parts www.lightspares.com
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

VI528	3X10 SCREW
298.002	REAR PANEL HOLER
MEPR07	MAINS PLUG IN
EL1204380	DMX XLR5 PCB
MEPR08	MAINS PLUG OUT
MV88	FERRITE CORE
VI614	2.9X6.5 SCREW
PLA175	CAP NUT Ø03
GR1442	SET SCREW D=4
VT402/1	LENS
DA212	NUT D=3
RD415	STAR WASHER D=5
A-LE54	LENS ASSEMBLY
298.040	SPACER
RL1297	FLAT WASHER D=3 L
RL409	FLAT WASHER D=3
GR3X20	D=3 SET SCREW
298.006	HEAT SINK
ETC339	STICKER BACK
ETC351	STICKER RIGHT SIDE
ETC354	STICKER LEFT SIDE
ETC319	STICKER YOKE RIGHT SIDE
ETC353	STICKER RIGHT SIDE
ETC352	STICKER LEFT SIDE
ETC340	STICKER YOKE LEFT SIDE
LE1296	FRESNEL LENS
PLA178	LENS HOLDER
VI848	3,5X6,5 SCREW
MMP450	LENS MOVING POLE
298.020	GASKET HOLDER
MMG166	GASKET
PLA179/1	UPPER CASING
PLA182	RIGHT SPRING HOLDER
VI5188	C/TERSUNK 3,5X13 SCREW
MO26/1	LOCKING SPRING
MO35	SPRING
PLA183	LEFT SPRING HOLDER
VI1062	4X12 SCREW
MMD381	TEFLON SPACER
MA14	KNOB
VI811	3,5X13 SCREW
298.032	RECEPTACLE COVER
DA231	SELF LOCK NUT D=4
VO877	BLADE HANDLE
VI527	3X8 SCREW



Your online store for all stage lighting spare parts www.lightspares.com
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

DA241	SELF LOCK NUT D=3
298.030	REAR BLADE PLATE
298.031	INNER PLATE
298.038	BAFFLE PLATE
MO54	SPRING
298.029	BLADE
PLA184	FRAME HOLDER
PLA179/1	LOWER CASING
ETC355	STICKER FRESNEL LEFT SIDE
ETC356	STICKER FRESNEL RIGHT SIDE



Your online store for all stage lighting spare parts www.lightspares.com
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria