

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

Spare Parts List of Martin Rush MH 1 Profile Plus

50480502	Fuse
50480503	Foot pad
50480504	Fast-locking buckle
50480505	Handle
50480507	Front/back cover
50480508	Left/right cover
50480509	Switch mode supply board
50480512	Driver board
50480516	Rotating gobo wheel
50480517	Rotating timing belt
50480518	Prism belt
50480519	Fixed gobo wheel
50480521	Plastic head cover
50480522	Plastic arm cover
50480523	Spindle core assembly
50480525	Vice board 1
50480526	Plastic yoke cover
50480527	Hall-element position board, Y-axis
50480528	Hall-element board B
50480529	Optical orientation plate
50480530	Tacho wheel
50480531	Step motor
50480532	Y-axis assembly
50480533	Timing belt
50480536	Switch power supply
50480625	Step motor for shutter
50480680	DMX board Multibeam 2
50480786	Pan belt MH 1+
50480787	Pos board tilt MH 1+
50480788	DC fan for LED MH1+
50480789	LED for MH 1+
50480790	Focuslens MH 1+
50480791	Base fan MH 1+
50480792	Mainboard Base MH 1+

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**