

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

Spare Parts List of Volkslicht 60 Zoom

25-024-0612-00	Aperture
28-002-0909-00	Lens Assembly
28-002-0924-00	LED PCB Assembly
25-017-0320-00	Rubber Ring, Black
25-005-0157-00	Nut for Stepping Motor
25-022-1868-00	Die-cast Head
08-001-0091-00	Stepping Motor
25-005-0158-00	Hexagon Copper Spacer
27-001-2124-00	KIT GLP impression Zoomdriver PCB
25-022-1871-00	Stepping Motor Cover 2
25-022-1870-00	Stepping Motor Cover 1
25-022-1872-00	Stepping Motor Cover 3
25-024-0572-00	Fan-case
08-002-0029-00	FAN
25-024-0573-00	Fan-cover
28-002-0822-00	Armcover Plastic (incl. VL Logo)
25-022-1773-00	Stopper Blade Tilt
25-022-1427-00	Bearing Spacer Tilt
28-002-0801-00	Bearing Block Tilt (asm)
23-001-4560-00	Armcover Front
22-007-0011-00	Stopper Nut Tilt
25-022-0918-00	Shaft Tilt
23-001-4562-00	Arm Mainframe
23-001-4561-00	Armcover Back
25-024-0566-00	Armcover Plastic Bottom
23-001-4567-00	Armcover Round
25-022-1632-00	Lockring Pan
28-002-0494-00	Bearing Block Pan (asm)
25-024-0284-00	Belt Tilt
08-001-0025-00	Steppingmotor Tilt
25-022-1767-00	Belttension Holder
25-022-1286-00	Gearwheel Tilt
28-002-0816-00	Belttension Bearing (asm)
25-022-1820-00	Special Washer
27-001-2051-00	Hall PCB Tilt Kit
27-001-1926-02	Motor Driver PCB Kit
25-022-1774-00	PCB Holder
25-022-1558-00	Encoder Holder Pan 1
25-022-1631-00	Encoder Holder Pan 2
27-001-2050-00	Feedback PCB Pan Kit
25-022-1772-00	Motorholder Plate
08-001-0090-00	Steppingmotor Pan
23-001-4566-00	Motorholder Pan
28-002-0487-00	Driving Gear Pan

28-002-0489-00	Encoder Wheel Pan
25-024-0285-00	Belt Pan
25-022-1799-00	Shaft Pan
25-024-0255-00	Bearing Ring
25-022-1635-00	Gearwheel Pan
28-002-0800-00	Lolly (asm. Incl. Magnet, etc.)
23-001-4570-00	Shaft Adaptor Arm
25-022-1224-00	Stopper Pan
27-001-2052-00	Hall PCB Pan Kit
22-001-0442-00	Stopper Nut Pan
25-017-0089-00	Rubber Ring (for Stopper Nut Pan)
23-001-4565-00	Motorholder Tilt
28-002-0488-00	Driving Gear Tilt (asm)
25-022-1826-00	Encoder Holder Tilt
27-001-2062-00	Feedback PCB Tilt Kit
25-024-0567-00	Armcover Plastic
24-005-1392-00	Volks??Licht Logo
28-002-0821-00	Top Basecover Plastic Kit (complete)
23-001-4572-00	Shaft Adaptor Base
10-011-0097-00	PSU
20-002-0022-00	Fuseholder
23-001-4687-00	Base Mainframe Side 1
11-001-0070-00	Main Switch
25-022-1769-00	Main Switch bracket
25-022-1768-00	Fuseholder bracket
27-001-2043-00	DMX PCB Kit
23-001-4559-00	Base Mainframe Bottom
25-024-0570-00	Bottom Basecover Plastic
25-022-1225-00	Handle
27-001-1924-00	Main PCB
27-001-2057-00	DCDC 9V Converter PCB Kit
25-022-1775-00	Display Holder
08-002-0081-00	Base Fan
25-022-1776-00	Clamp Cover
23-001-4688-00	Base Mainframe Side 2
27-001-2063-00	Temperature PCB Kit
25-006-0066-00	Rubber Rivet
23-001-4571-00	Clamp Holder
25-014-0023-00	Rubber Foot
24-005-1393-00	GLP Logo
28-002-0490-00	Top Basecover Plastic
24-005-1385-00	Display Film
25-008-0501-00	Display Window
25-020-0592-00	Isolation Sheet between PSU and Base Mainframe

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

