

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

## Complete Spare Parts List of Martin M2 PC

|          |                                                  |
|----------|--------------------------------------------------|
| 11501012 | 1.5 m power cable, 3-pin IEC                     |
| 04222003 | 10K Ohm Lin Fader 60mm                           |
| 08220701 | 6.3x0.8 Cable Spade Pop Rivet                    |
| 05501001 | Digiswitch                                       |
| 05551058 | Encoder knob black D=45 H=6 Axis=6 w. fingerhole |
| 05552010 | Faderknob ALPS-RS6011Y19004 Large                |
| 05120701 | Jumper 2 Pole 2,54mm Spacing                     |
| 05555217 | Keycap Cherry -                                  |
| 05555210 | Keycap Cherry .                                  |
| 05555218 | Keycap Cherry /                                  |
| 05555212 | Keycap Cherry @                                  |
| 05555216 | Keycap Cherry +                                  |
| 05555028 | Keycap Cherry <                                  |
| 05555027 | Keycap Cherry >                                  |
| 05555200 | Keycap Cherry 0                                  |
| 05555201 | Keycap Cherry 1                                  |
| 05555301 | Keycap Cherry 1 for LED                          |
| 05555310 | Keycap Cherry 10 for LED                         |
| 05555202 | Keycap Cherry 2                                  |
| 05555302 | Keycap Cherry 2 for LED                          |
| 05555303 | Keycap Cherry 3 for LED                          |
| 05555304 | Keycap Cherry 4 for LED                          |
| 05555305 | Keycap Cherry 5 for LED                          |
| 05555306 | Keycap Cherry 6 for LED                          |
| 05555207 | Keycap Cherry 7                                  |
| 05555208 | Keycap Cherry 8                                  |
| 05555308 | Keycap Cherry 8 for LED                          |
| 05555209 | Keycap Cherry 9                                  |
| 05555309 | Keycap Cherry 9 for LED                          |
| 05555221 | Keycap Cherry Clear (Large)                      |
| 05555222 | Keycap Cherry Copy (Large)                       |
| 05555229 | Keycap Cherry Cue (Large)                        |
| 05555224 | Keycap Cherry Delete (Large)                     |
| 05555219 | Keycap Cherry Edit (Large)                       |
| 05555211 | Keycap Cherry Enter (Large)                      |
| 05555213 | Keycap Cherry Full                               |
| 05555228 | Keycap Cherry Group (Large)                      |
| 05555227 | Keycap Cherry Load (Large)                       |
| 05555223 | Keycap Cherry Move (Large)                       |
| 05555000 | Keycap Cherry No text                            |

|          |                                            |
|----------|--------------------------------------------|
| 05555225 | Keycap Cherry Record (Large)               |
| 05555214 | Keycap Cherry Thru                         |
| 05555220 | Keycap Cherry Undo (Large)                 |
| 05555226 | Keycap Cherry Update (Large)               |
| 05555203 | Keycap Cherry 3                            |
| 05555204 | Keycap Cherry 4                            |
| 05555205 | Keycap Cherry 5                            |
| 05555206 | Keycap Cherry 6                            |
| 05555307 | Keycap Cherry 7 for LED                    |
| 05555215 | Keycap Cherry Arrow                        |
| 05555018 | Keycap Cherry Bank                         |
| 05555016 | Keycap Cherry Delay                        |
| 05555001 | Keycap Cherry F1                           |
| 05555002 | Keycap Cherry F2                           |
| 05555003 | Keycap Cherry F3                           |
| 05555004 | Keycap Cherry F4                           |
| 05555005 | Keycap Cherry F5                           |
| 05555006 | Keycap Cherry F6                           |
| 05555007 | Keycap Cherry F7                           |
| 05555008 | Keycap Cherry F8                           |
| 0555501  | Keycap Cherry Fade                         |
| 05555035 | Keycap Cherry Go (Large)                   |
| 05555023 | Keycap Cherry High Light                   |
| 05555019 | Keycap Cherry Last                         |
| 05555037 | Keycap Cherry Link                         |
| 05555034 | Keycap Cherry II/Back (Large)              |
| 05555017 | Keycap Cherry Macro                        |
| 05555014 | Keycap Cherry Menu                         |
| 05555020 | Keycap Cherry Next                         |
| 05555021 | Keycap Cherry Preview                      |
| 05555033 | Keycap Cherry Rel                          |
| 05555031 | Keycap Cherry Select                       |
| 05555032 | Keycap Cherry Snap                         |
| 05555015 | Keycap Cherry Snap Shot                    |
| 05555022 | Keycap Cherry Swap Prog                    |
| 91613090 | LED Desklamp Angular XLR 13                |
| 23007470 | Lid M2GO/M2PC                              |
| 08052701 | M3 nut lock PA shiny                       |
| 08050709 | M3x10 ph torx black                        |
| 08050702 | M3x6 ph torx black                         |
| 08050803 | M3x8 cs torx black                         |
| 08050703 | M3x8 ph torx black                         |
| 08110703 | M6x12 bh torx black                        |
| 11501502 | Mains cable 3x18AWG IEC-US, 3M Rev A and B |
| 62050021 | PCBA M2GO/M2PC Front                       |
| 34240006 | Plastic bag, 600x850                       |
| 34240018 | Plasticbag 250x360x40x0,04mm               |

08200102 PT 2,9x6,5 ph torx black  
32020504 Rubber foot  
02204506 TFT 3.5 320x240 8-16 bit parallel with Touch  
11840066 USB 2.0 Cable, 1m  
11040533 Wire yellow/green 1x0,75# 25cm

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**