

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of ARRI EB 2500

L4.82533.E	Diode module byt 261 PIV 800	Diodenmodul Byt 261 PIV 800
L4.82515.E	Low noise switch with knob	Noise-Schalter mit Drehknopf
L4.82513.E	Mains switch	Netzschalter
L4.82530.E	HF-converter board	HF-Wandlerkarte
L4.82531.E	LF-converter board	NF-Wandlerkarte
L4.82534.E	HF-choke (2 terminals)	HF-Drossel (2 Klemmen)
L4.82529.E	Electr. voltage supply board	Elektr. Spannungsversorgung
L4.82502.E	Rubber foot-set cpl. (4 pieces)	Gummifuß-Set kompl. (4 Stück)
L4.82532.E	Power FET module	FET Modul TSD 4 M 450 V
L4.82527.E	Control board	Regelkarte
L4.82528.E	RF-line filtering board	RF-Netzfilter
L4.82526.E	Front handle-set cpl.	Frontgriff-Set kpl.
L4.82537.E	Input capacitor 1800 MF/400 V	Ladeelko 1800 MF/400 V
L4.82538.E	Ignition resistor-set (10 pieces)	Zündwiderstand-Set (10 Stück)
L4.82510.E	Input rectifier	Netzgleichrichter
L4.82516.E	Dimm pot with knob	Dimmpotentiometer mit Drehknopf
L4.82517.E	Start resistor-set (5 pieces)	Startwiderstand-Set (5 Stück)
L4.82514.E	Earth test switch	Erdtaster

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

