

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of ARRI EB 575/1200

L4.82593.E	Front handle	Frontgriff
L4.82597.E	Mains board	Trafokarte
L4.82509.E	Diode	Diode
L4.82604.E	IGBT-Module	IGBT-Modul
L4.82598.E	Input capacitor board	Elkokarte
L4.82510.E	Input rectifier	Netzgleichrichter
L4.82599.E	LF-converter board	NF-Wandlerkarte
L4.82601.E	Main circuit breaker	Netzautomat
L4.82600.E	Front panel board	Frontplatine
L4.82602.E	ON/OFF switch	Ein/Aus-Schalter
L4.82508.E	Power Fet	Power Fet
L4.82594.E	Control board	Regelkarte
L4.82595.E	LF-base drive board	NF-Ansteuerung
L4.82596.E	HF-base drive board	HF-Ansteuerung
L4.82603.E	Dimm pot with knob	Dimmpotentiometer mit Drehknopf
L4.82502.E	Rubber foot-set(4pc)	Gummifuß-Set kpl. (4 Stück)

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria