

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

Spare Parts List of PR Lighting Pilot 300 ©

040010044 TRANSFORMER 240V, 50/60Hz
040010036 TRANSFORMER 230V, 50/60Hz
040010039 TRANSFORMER 220V, 50/60Hz
040010041 TRANSFORMER 200V/60Hz
190010065 Thermostat 75° C / 10A
140010018 Capacitor 60µF/370V
040070024 Ballast 230V/50Hz
040070025 Ballast 220V/60Hz
040070029 Ballast 200V/60Hz
190010054 Thermostat 95° C / 10A
040090020 Ignitor 240V/50-60Hz
040090016 Ignitor 230/220V/50-60Hz
040090009 Ignitor 230/220V/50-60Hz
100050023 Lamp HTI 300W/DX
191010028 Touch Switch
030069006 Fan DC 24V
030040047 Prism Rotation Motor 17HS0002-38
030040023 Prism Motor 42BYGH023-16
030040023 Focus Motor 17HS0002-38
030040024 Gobo Motor 17HS0002-03
030040023 Gobo Rotation Motor 17HS0002-38
030040024 Color Motor 17HS0002-03
030040023 Shutter Motor 1, 17HS0002-03
030040024 Shutter Motor 2, 17HS0002-38
030040052 Motor Tilt 23HS0015
030040053 Motor Pan 23HS2029
170050010 IC Driver Chips
170110004 IC Driver Chib
170050001 Arithmetic Amplifier Chip
170110004 IC Driver Chib
170040014 IC TTL LOGICAL CHIP
170170037 IC D/A REVERSION CHIP
170040014 IC TTL Logical chip
170170039 IC Stable Voltage Chip
170170012 IC Bus Chip for receiving/transmitting
170040033 IC EEPROM
230040120 IC Microprocessor
290151217 Pan Drive Belt 309-3M-103Z 103 TEETH
290151218 Tilt Drive Belt 170110004

