

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

Spare Parts List of PR Lighting XS 250©

040030039 TRANSFORMER 21V 100W/230V 320W
190010065 THERMOSTAT 175?
040070022 BALLAST 230V 50/60Hz
040090016 IGNITOR 230V 50/60Hz
100050057 LAMP MSD250/2
290151252 TILT DRIVE BELT HTD-612-3M
290151251 PAN DRIVE BELT HTD-447-3M
030060057 FAN IN BASE DC24V/2.88W
030060053 FAN NEAR THE LAMP 24V 1.4W
030040053 PAN MOTOR 57BYGH301-3A
030040052 TILT MOTOR 57BYGH101-2A
030040095 PRISM ROTATION MOTOR 17HD0013-36L
030040095 SHUTTER BLADE 1 MOTOR 17HD0013-36L
030040095 SHUTTER BLADE 2 MOTOR 17HD0013-36L
030040132 ROTATING GOBO WHEEL MOTOR 14HD0013-31L
030040132 PRISM/FROST MOTOR 14HD0013-31L
030040148 ROTATING GOBO WHEEL 2 MOTOR 17HD0013-62
030040112 FOCUS MOTOR 17HD0013-38L 5*15
030040112 FIXED GOBO WHEEL MOTOR 17HD0013-38L 5*15
030040112 COLOUR WHEEL MOTOR 17HD0013-38L 5*15
230020252A MOTOR DRIVE PCB
230020249 DISPLAY PCB

