

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

**Complete Spare Parts List of
LTM Prolight 4000**

2115P100	STRIKER ASSEMBLY
2115P106	PLATE, HEAT SHIELD TOP DRAWER
2115P107	SHIELD, HEAT SIDE
S 1061 03	DRAWER - NOT EQUIPPED
S 1061 02	DRAWER, BACK CASTING
S 1061 06	SPACER, BAR STRIKER HOUSING
S 1061 01	DRAWER, FRONT CASTING
S 1061 07	SUPPORT, TEFLON MICRO SWITCH CABLE
2115P108	SUPPORT, TEFLON H.T. SWITCH CABLE
S 1061 22	SUPPORT, COMPONENT
S 1061 12	CASTING STRIKER INSULATING
602388	SPACER STRIKER
606437	POWER INDICATOR RED
606290	PUSH BUTTON RED
606434	POWER INDICATOR ORANGE
606291	PUSH BUTTOM GREEN
606612	HOURS COUNTER
2115P110	INPUT CABLE
605287	CABLE 12G1,5
606737	VEAM CONNECTOR
606703	STRAIN RELIEF BUSHING
606706	GROMMET
606704	LOCKNUT
286P100 02	STRIKER BOARD ASSEMBLY EQUIPPED
A 672 01 B	P.C. BOARD
S 1136	TRANSFORMER REF:2796
607213	CAPACITOR

S 903	SCREW STRICKER CAP
S 1193	BRACKET SPARK GAP
S 1192	IGNITION POINTS EQUIPPED
602058	CONNECTION POINT
607164	DIODE
607526	CAPACITOR
607813	RESISTOR
600320	BLOCK H.T. REF:3162
Y729370	CAPACITOR
Y311010	TERMINAL BLOCK 3 PIN
Y311020	TERMINAL BLOCK 4 PIN
606608	RELAY SOCKET
606607	RELAY
606609	RELAY HOLDING CLIP
607243	CAPACITOR
Y010730	RESISTOR
S 1187 04	CONTROL BOARD TERMINAL STRIP 8 PIN
607807	MALE TERMINAL BLOCK 13 PIN
607804	FEMALE TERMINAL BLOCK 13 PIN
607808	MALE TERMINAL BLOCK 6 PIN
607806	FEMALE TERMINAL BLOCK 5 PIN
607515	RESISTOR
S 1230	BOARD STRIKER TIMER
2115P109	CABLE H.T.
S 1061 05	STRIKER COVER
S 1061 23	SCREEN H.T.
S 758 01	LABEL LAMP MOUNT WARNING - FRENCH
S 768 02	LABEL LAMP MOUNT WARNING - ENGLISH
211BP200	HOUSING EQUIPPED
2115P211	SUPPORT, FRONT DOOR
2115P209	LIFT CASTING SIDE SUPPORT
602381	SPACER
2115P201	RIGHT CASTING SIDE SUPPORT

2115P210	CASTING, LOWER
264N218	CASTING, UPPER ROOF
2115P206	CASTING, BACK SUPPORT
602325	LIFTING EYE
264N205	OUTSIDE BAFFLE
2115PT209	INSIDE BASE BAFFLE
2115PT208	INSIDE HEIGHT BAFFLE
2115PT202	INSIDE HEIGHT BAFFLE
2115PT201	INSIDE BASE BAFFLE
S 1061 08	SUPPORT, HANDLING WHEEL
S 1061 15	SUPPORT, HANDLING WHEEL
264N211	WHEEL HANDLING
602340	CAP, RUBBERT INSERT
602341	PEG, FOR RUBBERT INSERT CAP 602340
S 231	AXEL DOOR LATCH
S 230	SPRING DOOR LATCH
S 184	KNOB DOOR LATCH CLOSING
A 64 04	DISK, FRICTION
2115P300	CHARIOT ASSEMBLY
2115K301	CHARIOT
S 1360 01	SOCKET CASTING
S 960 01 02	SPRING, FEMALE CONTACT
S 960 04	FEMALE CONTACT
602172	FLAT WASHER
602174	NUT
680030066	BLIND NUT
2115P312	SUPPORT, REFLECTOR RING
S 912	REFLECTOR
2115P305	CABLE HOLDING
2115P309	CHARIOT SUPPORT
2115P311	CHARIOT SUPPORT
2115P313	SCREW, ADJUSTING
2115P314	GUIDE ROD

S 328	FOCUS KNOB
2115P306	CABLE SPACER
2115P400	DOOR FRONT EQUIPPED
2115P401	DOOR FRONT MOUNTED
S 212	BRACKET FIXED FILTER
S 213	SUPPORT BRACKET - HINGED FILTER
S 214	BRACKET HINGED FILTER
S 178	SPRING
S 215	AXLE FILTER BRACKET
680700720	FRESNEL LENS
2115P410	SCREEN SAFETY
259 AXLE	DOOR
2115P500	DOOR, REAR - ASSEMBLY
S1061 11	REAR BAFFLE
264N501	DOOR, REAR - NOT EQUIPPER
264N214	SILICONE SCREEN
264N215	TEFLON SCREEN
2115P601	PLATE, I.D. - ROUND
2115P600	YOKE ASSEMBLY EQUIPPED
2115P601	YOKE NOT EQUIPPED
2115P603	YOKE SUPPORT
S 1325 02	SPACER, YOKE CUP
2115P602	SPACER
604572	SCREW
602418	KNOB YOKE
2115P7Ö0	SWITCH MICRO EQUIPPED
S 106114	BRACKET SWITCH
S 1062 06	BRACKET SWITCH SUPPORT
S 178	SPRING
2116P702	ROD LONG SWITCH
606581	SWITCH
2115P701	BRACKET, GUIDE SWITCH
S 1290	TIP SWITCH - METAL BULLET

ACCESSORIES

A 261	GEL FRAME
M 435230	SINGLE SCRIM 1/1
M 435232	DOUBLE SCRIM 1/1
M 435231	SINGLE SCRIM 1/2
M 435233	DOUBLE SCRIM 1/2
A 26	4 LEAF BARNDOOR
A 734	HEAD CABLE EXTENSION 10m
A 428	MAGNETIC BALLAST ALIMARC 2500 <230V/50Hz)
A 429	MAGNETIC BALLAST ALIMARC 2500 (120V/60Hz)
593007	ELECTRONIC BALLAST 2500/4000
A 507	SHUTTER GRADALUX

*Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria*