

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

## Complete Spare Parts List of High End Systems Hog iPC

25091327	Track Ball Adapter Plate
74080005EF	TOUCHSCREEN DISPLAY 12" ELO 1215L
25091315	TIMECODE READER/GENERATOR PLCC IC 2008B
90409208	SWITCH ASSEMBLY MOMENTARY WITH GUARD
91500510	SCREWS, Front Panel
99320154	ROADCASE BOX
74070001	ROADCASE
90904002	POWER SUPPLY 300W CPU
80030079EF	PCB, TIMECODE
80030063	PCB, MIDI IN/OUT
80040056	PCB, FRONT PANEL
80030097EF	PCB, DMX OUTPUT X4
99260473	MOUNT CDR WITH HARD DRIVE W/O SLOT
80430126	MOTHERBOARD ASSEMBLY, includes RAM, Processor, Hard Drive, Timecode PCB, etc.
99260467	MONITOR MOUNTING PLATFORM, FOR DISPLAY MODEL 1229L ONLY
60600244	MANUAL
90409212	HARNESS, USB
90409310EF	HARNESS, MAIN
25091424EF	HARD DRIVE, IDE
90903003EF	HARD DRIVE, S-ATA
25090003	FADER KNOB
90405330EF	FADER 60mm
25091144	ENCODER KNOB
90306086	ENCODER
80070387	ENCLOSURE ASSEMBLY
25091108	ELBOW REST
74080001	DUST COVER
25091466	DESKLIGHT POUCH 12" LED
25091472	DESKLIGHT CABLE LOOM
61040029	DESKLIGHT 12"
90803030	CORD 3-WAY IEC SPLITTER 6'
25091508	CONSOLE, KEYCAP PRINTING
25091419	CD WRITER
61090001	BUTTON CAP: PLEASE SPECIFY SIZE, TEXT, LED, ETC
25090011	BUTTON STANDARD
25090010	BUTTON FLASH
99260451	BRACKET, TRAY, CIRCUIT BD MNT IPC
90604008	BATTERY , LITHIUM 3V CR 2032
99190089	ARM REST HINGE

25091112	4 LED LIGHTPIPE
25091097	4 LED FLEXI/RIGID PCB MK1 21-02-2001
80430131	Video Card Replacement Kit
25091077	TRACK BALL W/BICOLOUR BLKLIGHT
25091328	TRACK BALL CABLE LEAD ASSY
25091105	TRACK BALL BUTTON

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**