

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of Martin Mac 575 Krypton

02121014 6204 Driver Chip
02121015 6205 Driver Chip
04030082 80uF Capacitor w/ Plugs
04541530 Ballast (Magnetic)
05020025 Fuse, 10A (Mains In)
05031004 Fuse Holder Assembly (Mains In)
05520503 Microswitch (Pan)
05701804 Motor (Pan)
05801001 3V Lithium Battery (Main PCB)
06150006 SMPS
11521017 Mains Cable
16040050 Belt (Pan)
18400030 Optical Encoder Wheel (PanFB)
55245018 Cover (Base Top - w/ Film)
55245019 Cover (Base Top - w/ Label)
62000093 Display PCB
62000140 Main PCB
62000144 Inrush/Relay PCB
62003013 Temperature Sensor (Base -BTER)
62003015 Optical Sensor (Pan FB)
62004624 xLR PCB (3P/5P - M/F)
62006021 Mains Filter PCB
62011514 Power Supply PCB (DC-DC)
62222082 Fans (Base)
04401102 Magnet (All Effect Wheels)
05040039 110° Thermosensor
05221209 Lamp Socket
05520503 Microswitch (Lamp Door)
05520504 Microswitch (Focus)
05701602 Motor (Iris, Prism Rotate)
05701603 Motor (Gobo Rotate)
05701606 Motor (Prism In/Out)
05701610 Motor (Shutters)
05701611 Motor (Gobo 1,Gobo 2,Col 1,Col 2,Zoom,Focus)
06020029 Starter
16040240 belt (Focus Short)
16040250 Belt (Focus Long, Zoom)
16040430 belt (F. Gobo, R. Gobo, Gobo Rotate, Color 1)
16040440 Belt (Prism In/Out)
16040470 Belt (Color, Prism Rotate)

16040510 Belt (Iris)
17300020 plastic Adaptor for Color Filters
17760380 Conical Spring for Gobos
20800170 Air Filter
41002090 Reflector
41102070 Heat Filter (Glass Only)
41203020 Lensgroup 1 (Front Lens)
41203025 Lensgroup 2 (Zoom Lens)
41203030 Lensgroup 3 (Focus Lens)
41500026 Iris
55240003 Cover (Main Head w/ 1/4 Turns)
62003019 Hall Sensor (Color 2, Fixed Gobo)
62003020 Hall Sensor (Gobo Rotation)
62003025 Hall Sensor (Rot. Gobo Wheel)
62003029 Temp Sensor (Lamp)
62003032 Hall Sensor (Color 1)
62003036 Microswitch PCB (Zoom)
62222049 fan (Gobo Module - Both are the Same)
62323038 Heat Filter Module (Assembled)
62325093 Shutter Blade (Universal)
62325121 Fixed Gobo Wheel w/ Gobos
62325122 4 Facet Prism in Adaptor
62326079 Color Wheel 1 w/ Colors
62326080 Color Wheel 2 w/ Colors
62326087 Rotating Gobo Wheel w/ Gobos
62400319 Rotating Gobo Guide w/ Bearings
62400506 Fan Assembly (Lamp Section-Pair)
05520506 Microswitch (Tilt)
05701804 Motor (Tilt)
11860089 wireset (Yoke to Head - 1/2/3)
11860212 Wireset (Yoke to Head - Zoom/Focus)
16040090 Belt (Tilt)
18400030 Optical Encoder Wheel (Tilt FB)
55225627 Cover (Arm)
55225704 Cover (Arm with Tilt Lock)
62003008 Optical Sensor (Tilt FB)
08240609 Butterfly Latch
19400060 Castor (Wheel)
34204023 Foam (Yoke - Side - 1 pc)
34204064 Foam (Lid and Top - Base Support - 2 pcs)
34204066 Foam (Bottom - Front Lens Support - 1 pc)
08052701 M3 Lock Nut (Holds Main PCB to Plate)
08070502 screw (Base Covers - Top)
08111214 M6x30mm Allen Screw (Wheels to Case)
08240107 1/4 Turn Retaining Ring (Head Cover)
08240113 1/4 Turn Wingbolt (Omega Bracket)
08240114 1/4 Turn Retainer (Omega Bracket)

08240127 1/4 Turn Receptacle (Head Cover)
08240134 1/4 Turn Stud (Head Cover)
08240135 1/4 Turn Spring (Head Cover)
97010230 Replacement Lamp - GE CSR575/S/DE/70
91602001 Omega Bracket
91602008 Omega Bracket (T-Shaped)
91510020 Flightcase (Empty)
90216100 MAC575 Krypton in Cardboard (Black)
90216030 MAC575 Krypton in Cardboard (White)

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**