

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

## Complete Spare Parts List of Clay Paky Sharpy

699189	(new)CPU brd--base--Newdisplays
699179	(old)CPU brd--base--Newdisplays
699170	displayCPU
DIP001/001	Display
699190	(replaced)base-User Interface DisplayCP0101
699170	(old)-base-User Interface DisplayCP0101
699175	base8AT2x71Pan2TiltCP0108
699174	base8AT2x71Colour wheel2Stopper-strobe/dimmer3Static gobo4Effects movement5Prism rotation6Prism insertion7Frost8Focus
694003/002	Power supply cord
252999/801	Power wire harness (main switch, terminal block, cut-out, transformer, CP0100, CP0101, battery, ballast, CP0108, fans, ground contacts) + Bus wire harness
650077/002	Transformer-ballast wire harness
650085/001	CP0100-CP0105 wire connection
650093/003	Bus wire harness
650207/001	Gobos, colours, prism, dimmer, shutter, focus, frost board wire harness (from boards to D-connectors)
650207/002	Gobos, colours, prism, dimmer, shutter motors wire harness (from D-connectors to motors)
650207/004	Prism, frost motors wire harness (from D-connectors to motors)
650207/006	Focus motors wire harness (from D-connectors to motors)
650208/001	Pan & Tilt wire harness (encoders, motors, sensor)
031945	Focus Single threaded movable shaft57mm long
031960	Startic gobo change Single shaft, 16.5mm long
031960	Effects movement Single shaft, 16.5mm long
031970	Pan Single shaft, 25mm long
031947	Tilt Single shaft, 27mm long
031976	Top dimmer blade Single shaft, 21.5mm long
031961	Bottom dimmer blade Single shaft, 26.5mm long
031965	Colour Wheel Single shaft, 16mm long
031969	Frost insertion Single shaft, 13mm long
031969	Prism Insertion Single shaft, 13mm long
031975	Prism rotation Single shaft, 28mm long
251080/801	VAC003PAPST type 8414 NM24DC-1.4INLET1Lamp -A
251080/802	031980NIDEC SERVOE0515H24B7AZA0124DC-1.9INLET1Lamp -A
251079/801	031931PAPST type 614 F24DC-1.1TO DRIVER1Base -B
251079/802	031931PAPST type 614 F24DC-1.1TO PSU1Base -C
252087/801	Complete colour wheel
088410/014	Dicroich filter A3005 Dark RedLW640
088410/013	Dicroich filter A029C Dark YellowLW550(Orange)
088410/012	Dicroich filter F1304 AcquamarinePWB450

088410/011	Dicroich filter Green5054(Deep Green)
088410/010	Dicroich filter A162I Light GreenWB505
088410/009	Dicroich filter F1201 LavanderPSL440
088410/008	Dicroich filter A1177 PinkSL4758
088410/007	Dicroich filter YellowLW520
088410/006	Dicroich filter A2502 MagentaSL4763
088410/005	Dicroich filter CyanSW530
088410/004	Dicroich filter D3003 TC260(CTO2)
088410/003	Dicroich filter D2904 TC190(CTO1)
088410/002	Dicroich filter D2801 DL070(CTB)
088410/001	Dicroich filter A3102 BluSW460(Dark Blue)
030361/001	Main Switch 6A
031745	Battery 6V 1,2Ah (25x97x51mm)
031760	Ferrite
031882	PSU-SMPS 28/6 400-0,5(Schiederwerk)
031883	Lamp Driver (PHILIPS EUC 190d NT01)
ALI004	Lamp Driver (OSRAM SIRIUS HRI 190W+)
650080/001	Thermal cut-out 100°C with connector 100° (Effects)
021784	Belt -GT3 0393-3MGT-9 h=9 PAN
021799	Belt -HTD 0447-3M-9 h=9 –TILT
021780	Belt -888 MXL 025 –EFFECTS MOVEMENT
021781	Belt -680 MXL 018-PRISM
021782	Belt -1200 MXL 012–PRISM
DPI001/001	LCD Display Board
699174	8 Motors Driver Board (CP0108)
699175	Pan & Tilt electronic board (CP0101)
699176	Pan & Tilt Encoder Board(CP0109)
699177	Hall sensor Board(CP0130)
699178	User push button board
699189	CPU electronic board (CP0100)
699184	DMX connectors board (CP0112)
251079/801	Fan PAPST 614F (031931) withconnector -BASE
251079/802	Fan PAPST 614F (031931) withconnector -BASE
251080/801	Fan PAPST 8414NM (031955) withconnector -LAMP
251080/802	Fan NIDEC SERVO (031980) withconnector -LAMP
031945	Stepper motor, single shaft 14HY7006-02X-A –FOCUS(2)
031947	3 phase stepper motor, single shaft 24HC4301-01 (L=27mm) -TILT
031960	Stepper motor, single shaft (L=16,5mm)STATIC GOBO CHANGE / EFFECTS MOVEMENT(2)
031965	Stepper motor, single shaft (L=16mm) -COLOUR WHEEL
031969	Stepper motor, single shaft (L=13mm) –FROST / PRISM INSERTION
031970	3 phase stepper motor, single shaft 24HC2302-04 (L=25mm) -PAN
031975	Stepper motor, single shaft (L=28mm) –PRISM ROTATION
031976	Stepper motor, single shaft (L=21,5mm) –DIMMERS
650208/001	Pan & Tilt wire harness (encoders, motors, sensor)
650207/001	Gobos, colours, prism, dimmer, shutter, prism, frost, focusboard wire harness
650085/001	CP0100-CP0105 wireconnection

694003/002	Power supply cord
650207/002	Gobos, colours, prism, dimmer, shutter motors wire harness
650077/002	Transformer-ballast wire harness
252999/801	Base wire harness (main switch, terminal block, cut-out, transformer, CP0100, CP0101, battery, ballast,lamps,CP0108, fans, ground contacts)
650093/003	Bus wire connection
650207/004	Prism, frost motors wire harness
650207/006	Focus motors wire harness
233999/003	Powercon-main switch wire harness
030258	Cable connector
030257	Chassis connector
080339/002	IR-UV cut-filter (47X47mm)
252020/801	Prism assembly
252036/801	Frost blade assembly
252049/801	Dimmer blade assemblyLOW
252049/802	Dimmer blade assemblyHIGH
252087/801	Complete Colour Wheel
252093/801	Objective lens
252110/801	Static gobo wheel
L10103	Lamp PHILIPS MSD Platinum 5R
LAM002	Lamp OSRAM SIRIUS HRI 190W+
082070/001	Elastic frontal back panel
092004/801	Elastic anterior collar
251090/801	Metal Base cover
252013/801	Elastic central yoke cover
252014/801	Elastic yoke cover
252014/802	Elastic yoke cover(with hole for lever)
252015/801	Effects assembly cover + rubber junction+ grill
252015/802	Effects assembly cover+ grill
030649/001	Marrierta white grease –10 gr.
030678	Magnet Ø=3mm h=6mm (T.max 180°C)
030681/001	Magnet Ø=3mm h=1.5mm (T.max 350°C)
030685/001	Magnet Ø=3 h=3 (T.max 350°C)
030691/001	Aluminium adhesive tape (180°C)20cm

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**