




PROFESSIONAL SHOW LIGHTING

ASTRORAGGI POWER

HSR 400

RICAMBI
SPARE PARTS
PIECES D'ETACHES
ERSATZTEILE UND SONDERZUBEHÖR
PARTES DE REPUESTOS

ASTRORAGGI POWER



ASTRORAGGI POWER
C11026

N.	Cod.
1	175010/001
2	130001/001
3	020031/003
4	020201/003
5	020210/007
6	175016/001
7	020004/006
8	020002/009
9	030120
10	030956
11	020002/014
12	080783/001
13	020204/001
14	020604/001
15	175019/001
16	020002/010
17	020106/003
18	020210/001
19	030983
20	030121
21	030122
22	030919
23	030311
24	175002/001
25	030007
26	020106/002
27	020201/002
28	020031/001
29	081948/007
30	080763/001
31	080764/006
32	020106/006
33	020201/005
34	175011/001
35	031302
36	L10047
37	175023/003
38	175023/004
39	175001/001
40	175020/801

N.	Cod.
41	030210
42	030404
43	030310
44	699046/801
45	160003/001
46	154013/001
47	030708/002
48	030709
49	020002/041
50	175005/001
51	030783
52	020106/004
53	175006/801
54	030303
55	175004/001
56	175007/801
57	175003/001
58	175008/001
59	175009/001
60	020026/003
61	175017/001
62	081915/003
63	020210/005
64	020210/004
65	030798
66	080812/001
67	150014/001
68	020016/002
69	175022/001
70	175012/001
71	125010/001
72	081408/001
73	080419/001
74	080503/001
75	020006/002
76	160015/001
77	081004/001
78	175026/001
79	020002/003
80	020002/002

N.	Cod.
81	020031/002
82	020002/008
83	020026/003
84	020211/001
85	
86	
87	
88	
89	
90	
91	
92	
93	
94	
95	
96	
97	
98	
99	
100	
101	
102	
103	
104	
105	
106	
107	
108	
109	
110	
111	
112	
113	
114	
115	
116	
117	
118	
119	
120	

N.	Cod.
121	
122	
123	
124	
125	
126	
127	
128	
129	
130	
131	
132	
133	
134	
135	
136	
137	
138	
139	
140	
141	
142	
143	
144	
145	
146	
147	
148	
149	
150	
151	
152	
153	
154	
155	
156	
157	
158	
159	
160	

